



Plibrico Company, LLC

1935 Techny Road - Unit 16

Northbrook, IL 60062

(312) 337-9000

www.plibrico.com

Plibrico Heat Up Schedule

Redline Schedule 1

Low Moisture Castable Refractories

Redline Schedule 1 heat up guide applies to Plibrico's family of Redline low moisture, low porosity castables and should be followed as closely as possible. After the castable is installed, 24 hours of air dry time is recommended prior to beginning the bake out procedure. After curing, follow the heating rate shown on the chart.

NOTE: If pressure steaming should occur at any time during the bake out, the procedure should be put on hold until the steaming subsides, it is not necessary that the steaming stops completely. The schedule should then resume from the point of interruption.

For questions, please consult your Plibrico representative or the Plibrico Technical Department.